



**TEAIS APAREJO MICROCEMENTO, Special plaster used to regularize a tile floor before applying TEAIS MICROCEMENTO.**



## Descripción

TEAIS APAREJO MICROCEMENTO is a special mortar, suitable for the ceramics supports regularization and finishing with TEAIS MICROCEMENTO.

## Aplication

It is applied to regularize ceramic tiled surfaces, chipboard, and other supports where regularization is needed before applying TEAIS MICROCEMENTO.

## Surface preparation

The support must be clean, free of grease or oil, firm, without loose parts and dry.

## Modes of application

- Mix manually or mechanically the liquid with the powder component until a thixotropic paste is obtained.
- Mix manually or by using a low speed mixer(300 to 500 r.p.m.).
- Let stand 2-5 minutes before using.
- Apply a first thin coat with a stainless steel to cover only the joints; the surface should be clean and dry.



📍 Avda. da Enerxía, nº 153, Pol. Ind. de Sabón  
15143 Arteixo, A Coruña  
☎ Telf.: 981 602 111  
📠 Fax.: 981 601 508  
✉ Email: desarrollo@teais.es

síguenos en:



- Let dry and apply a coat of our primer IMPRIDUR.
- Let it dry and apply another coat covering all the surface with TEAIS APAREJO MICROCEMENTO.
- Allow to dry before applying TEAIS MICROCEMENTO

## Clean up

---

The tools are cleaned with water while the material is fresh.

## Data sheet

---

Adherence > 0,5 N/mm<sup>2</sup>

Mass of density 1,76 kg/lt

Mix proportion 3 part of powder for 1 part of liquid

Open time > 20 minuts at 20°C

## Performance

---

1,5 to 2 kg/sqm

## Storage

---

Two years in their original containers tightly closed. Protected from weather and stored in a cool and dry place.



📍 Avda. da Enerxía, nº 153, Pol. Ind. de Sabón  
15143 Arteixo, A Coruña  
☎ Telf.: 981 602 111  
📠 Fax.: 981 601 508  
✉ Email: desarrollo@teais.es

síguenos en:

