



Descripción

MORIS INHIBIDOR is a thixotropic reparation mortar without retraction which contains inhibitor additives against corrosion. This allow quick reparations in structures made of armoured concrete affected by the corrosion on armours with one single product. It is not necessary to use other specific products on the iron.

Aplication

MORIS INHIBIDOR is used to repairing concretes affected by corrosion on armours, in all types of structures, pillars, beams, balconies, tiles, slabs, etc.

Surface preparation

The support must be clean, free of dust and any particles that can reduces the adherence.

Modes of application

It is must be blended directly with a percent of $\pm 2\%$ of water until obtain the suitable quantity to achieve the required plastic mass in order to apply it easily. The blended can be done manually or with an low-revolution electric mixer (300-500 rpm).

- Is suitable to let rest the admixture from 2 to 5 minutes before using.
- It must be applied by a trowel or palette with thickness below 3 cm per layer to avoid the spreading of the

material mainly in vertical planes.

Clean up

The tools must be cleaned with plenty of water while the mortar is wet.

Data sheet

Density

Water absorption

Compressive resistance > 300 kg/cm²

Flexural strength resistance > 80 kg/cm²

A1 class.

Performance

20 kg/sqm by each 1cm of thickness

Storage

One year in their original packages protected from the weather. Stored in a coll and dry place.

Security



Indications of danger:

H315: H315: Causes skin irritation.

H317: H317: May cause an allergic skin reaction.

H318: H318: Causes serious eye damage.

H335: H335:May cause respiratory irritation.

Prudence advice:

P271: P271:Use only outdoors or in a well-ventilated area.

P280: P280:Wear protective gloves/protective clothing/eye protection/face protection.

P302+P352: P302+P325:IF ON SKIN: Wash with plenty of soap and water.

P304+P340: P304+P340:IF INHALED: Remove victim to fresh air and keep at rest in a position comfortable for breathing.

P305+P351+P338: P305+P351+P338:IF IN EYES: Rinse cautiously with water for several minutes. Remove contact lenses, if present and easy to do. Continue rinsing.

P310: P310:Immediately call a POISON CENTER or doctor/physician.

P403+P233: P403+P233:Store in a well-ventilated place. Keep container tightly closed.

P501: P501:Dispose of contents/container in accordance with local/regional/national/international regulation



📍 Avda. da Enerxía, nº 153, Pol. Ind. de Sabón
15143 Arteixo, A Coruña
☎ Telf.: 981 602 111
📠 Fax.: 981 601 508
✉ Email: desarrollo@teais.es

síguenos en:

